

■対象製品の外観、確認方法

1. 対象商品の外観



FC-6800



FC-R8000



FC-9000



FC-R9100



FC-R9100P

2. 確認方法

クランクアーム内側 (黄色枠：製品モデル名、青色枠：製造刻印) ⇐



KF, KG, KH, KI, KJ, KK, KL, ⇐

LA, LB, LC, LD, LE, LF, LG, LH, LI, LJ, LK, LL, ⇐

MA, MB, MC, MD, ME, MF, MG, MH, MI, MJ, MK, ML, ⇐

NA, NB, NC, ND, NE, NF, NG, NH, NI, NJ, NK, NL, ⇐

OA, OB, OC, OD, OE, OF, OG, OH, OI, OJ, OK, OL, ⇐

PA, PB, PC, PD, PE, PF, PG, PH, PI, PJ, PK, PL, ⇐

QA, QB, QC, QD, QE, QF, QG, QH, QI, QJ, QK, QL, ⇐

RA, RB, RC, RD, RE, RF ⇐